



TerraDrain Sheet Drains

Installation Instructions

TerraDrain sheet drains are provided in a 4' x 50 roll for ease of handling and installation. Wall surfaces and footings should be free of voids and relatively clean. Depending on the type of substrate, TerraDrain can be installed using mastic sealant, pneumatic driven nails, or metal stick clips. When installing TerraDrain with waterproofing materials, the fastening system should be recommended and approved by the waterproofing manufacturer.

Begin placing the TerraDrain at the bottom of the wall, at the perimeter drain location. When installing adjacent rolls, pull filter fabric back to expose two rows of dimples, interlock the rolls and replace the fabric lap in the direction of the water flow. All terminal edges should be encapsulated with fabric lap to prevent soil intrusion into the open flow channels. Backfill and compact within 8 days. Gap-graded or broad graded soils are NOT recommended for backfill. Insure that the top edge of the TerraDrain is covered with a minimum of 6" of fill.

8/2004